



HSM-801AJ  
Series

# AUTOMATIC JANITOR

SIDEMOUNT for Urinals  
Troubleshooting Guide

## Troubleshooting Guide

PROBLEM	CAUSE	SOLUTION
Tone or "beeping" sound	Low battery indicator.	Replace batteries.
Not enough water to fixture or too much water to fixture.	Diaphragm damaged. Valve control stop improperly adjusted.	Replace diaphragm. Adjust valve control stop.
Valve will not operate.	Batteries are drained. Water supply is turned off. Relief valve (diaphragm plunger) is damaged.	Replace batteries. Turn water on. Replace relief valve (diaphragm plunger). If the unit does not begin to function, call customer service at 1-800-874-7822.
Valve does not shut off.	Dirt or debris preventing diaphragm from functioning properly.	Remove dirt or debris on diaphragm. Replace Diaphragm.



### Advanced Modern Technologies Corporation

19800 Nordhoff Place, Chatsworth, CA 91311  
Tel: (818) 883-2682 Toll Free: (800) 874-7822 Fax: (818) 883-2620  
[www.amtcorporation.com](http://www.amtcorporation.com)