ASD-600 HY-GENIE®
AUTOMATIC LIQUID SANITIZER DISPENSER
REFILL INSTRUCTIONS

Sanitizer Refill Instructions:

1. Flashing Red LED Indicates Low Sanitizer



2. Unscrew Liquid Sanitizer Bottle



3. Refill Liquid Sanitizer Bottle



4. Re-install Liquid Sanitizer Bottle



5. Press and <u>Hold Reset Button for 7 Seconds</u> to Prime New Soap and Reset Flashing Red LED.



For further assistance call technical support at 1-800-874-7822 or email technicalsupport@amtcorporation.com.